



Twist Drill

HSS · jobber drill

WOOD METAL MULTI MED

General drilling in wood, metal, plastic



Brad Point

Spur point · dowel bit

WOOD MED

Furniture making and joinery



Spade Bit

Paddle bit · flat wood boring bit

WOOD FAST

Fast, rough holes in softwood and timber



Forstner Bit

Flat-bottom bit

WOOD SLOW

Hinge recesses and mortises



Auger Bit

Brace bit

WOOD MED

Deep holes in solid timber



Self-Feed Bit

Power auger

WOOD FAST

Framing and construction timber



Hole Saw

Cup saw · holesaw kit

WOOD METAL MULTI SLOW

Door locks and latches



Countersink

82° countersink · rose bit

WOOD METAL MULTI SLOW

Before driving screws into wood or metal



Counterbore

Recess bit

METAL WOOD SLOW

Socket-head cap screws (Allen bolts)



Step Drill

Unibit · cone drill

METAL MULTI MED

Thin sheet metal and stainless enclosures



Masonry Bit

SDS bit · carbide-tipped

MASONRY FAST

Brick, block, concrete, mortar



Glass & Tile Bit

Spear bit · tile drill

TILE V. SLOW

Ceramic wall tile



Diamond Core Bit

Diamond hole saw

TILE SLOW

Porcelain and ceramic tile



Center Drill

Combined drill & countersink

METAL MED

Lathe centre holes



Plug Cutter

Bung cutter

WOOD SLOW

Hiding screw heads in furniture



Installer Bit

Fish bit · insulated bit

WOOD MULTI MED

Running cables and low-voltage wire



Multi-Material Bit

Universal bit

MULTI MED

Quick jobs across mixed materials



Self-Centering Bit

Hinge bit

WOOD MED

Cabinet hinge screw holes



Annular Cutter

Core cutter · mag-drill cutter

METAL MED

Thick steel plate and beams



Left-Hand Bit

Reverse-twist bit

METAL MED

Extracting snapped bolts and studs



Flex Auger

Bell hanger bit

WOOD MED

Awkward, angled holes in timber



Core Bit (Concrete)

SDS core · concrete core drill

MASONRY MED

Big holes in concrete for pipes and vents